


Rosen A10 DVD System Wiring Diagram



* **Optional Cables not included. Call Rosen Customer service to order**
 ** **IMPORTANT:** Do NOT allow the Blue wire to short to ground - system damage will result.
 ***Use the AC3194/AC3081 Cable for non Rosen AUX inputs